

1. To make the relief templates, preferably use as a support material a sheet of transparent plastic material and a black permanent marker.
2. Place the transparent sheet on the shape to trace and fasten the sheet by means of adhesive tape.
3. With an indelible marker pen, preferably black, outline the perimeter of the shape, which we generally advice to be **5mm on the outline of the slip-resistant surface**.
4. Write on the template in plastic material, name and surname, the chosen colour, the orientation of the same by adding the word bow and stern, right and left, in addition to the **reference of the model of the boat**.
5. In the case that the relief templates are more than one, number them with progressive numbers.
6. Take a picture of the templates before removing them from the boat.
7. **Do not cut the relief templates on the lines drawn with the indelible marker. Please leave an excess of transparent material of approximately 2 cm.**
8. Fill in the Customer Information Form and Positioning Templates received, which will be inserted into the pack together with the templates.
9. It is mandatory that the form be completed in its entirety, otherwise the form will be returned for the compilation of the missing parts.
Please draw/position, inside the contour boat on the form, the shapes of the template drawn with the number assigned to the same. Use the column to the left of the form to describe each numbered part.
10. If you want a logo, it must be indicated in the appropriate box on the form if it is a drawing or a text. Always note the number of the template where you want to the customisation to be affixed. Logos/texts for customisation must be supplied in vector graphics files or if not possible in .pdf file.
11. Once the reliefs of the templates have been made, we will make counter-templates for reference, designed with slats and frames and any logos and lettering and they shall be sent for a physical test on the boat.
12. Any corrections to the counter-template of reference will have to be made directly on them with red indelible ink marker and returned to us, signed.
13. Once we have received any corrections, it will be our task to bring them back to a technical drawing (draft) that will be sent for acceptance. Once you have reviewed and accepted the draft with changes, you will return it to us signed for acceptance.
14. Any sending of counter-templates of reference requested after the corrections must be expressly requested and will be billed at a cost of 30€, excluding shipping costs.

Important: To get a job as precise as possible, the relief templates and the reference templates must never be folded on themselves but rolled!

**COMPILARE LEGGIBILMENTE IL MODULO IN TUTTE LE SUE PARTI
LEGIBLY FILL THE FORM IN ALL ITS PARTS**

Company Name: Address: Telephone: Email:	Template Number and Description
Boat Make/Model/Year	1. _____ 2. _____ 3. _____ 4. _____ 5. _____ 6. _____ 7. _____ 8. _____ 9. _____ 10. _____ 11. _____ 12. _____ 13. _____ 14. _____ 15. _____
Colour Choice: CLASSIC: teak/black teak/white dark teak/black dark teak/white grey/black grey/white anthracite/black anthracite/white CUSTOM: _____ / _____ or 3mm: _____	SPORT: anthracite/yellow anthracite/orange anthracite/red anthracite/blue anthracite/green
Notes: Logo Cliente/Custom Logo:	
<p>The templates will not be processed without this card being completed entirely. If you send this incomplete form, we will send a request via e-mail with the form enclosed. The project will remain idle until this information will be provided.</p>	

